PETZL FOOTCORD PEDAL

https://www.securhit.com/en/pulleys-and-ascenders/560-pedale-foot-cord.html

PETZL FOOTCORD adjustable cord pedal, a practical accessory for use with the ASCENSION handle or BASIC rope clamp for successful rope ascents.



Description

Small accessories are becoming indispensable for certain activities, especially rope ascents. PETZL's FOOTCORD pedal remains the equipment of choice to simplify climbing.

- Simple, direct attachment to the ASCENSION handle or BASIC rope clamp for successful rope ascents.
- An adjustment plate to set the height of the pedal
- HDPE (high-density polyethylene) design for long service life
- Reliable support of the foot in the pedal thanks to an elastic band, which adjusts according to the type of shoe worn
- Easy pedal storage and transport

Weight: 40 g

Caractéristiques

- Materials : polyéthylène haute densité, aluminium