

## PETZL FOOTCORD PEDAL

<https://www.securhit.com/en/pulleys-and-ascenders/560-pedale-foot-cord.html>

PETZL FOOTCORD adjustable cord pedal, a practical accessory for use with the ASCENSION handle or BASIC rope clamp for successful rope ascents.



### Description

Small accessories are becoming indispensable for certain activities, especially rope ascents. PETZL's FOOTCORD pedal remains the equipment of choice to simplify climbing.

- Simple, direct attachment to the ASCENSION handle or BASIC rope clamp for successful rope ascents.
- An adjustment plate to set the height of the pedal
- HDPE (high-density polyethylene) design for long service life
- Reliable support of the foot in the pedal thanks to an elastic band, which adjusts according to the type of shoe worn
- Easy pedal storage and transport

Weight: 40 g

### Caractéristiques

- Materials : polyéthylène haute densité, aluminium